

SCHEMA ELETTRICO - WIRING DIAGRAM - SCHEMA ELECTRIQUE - SCHEMA ELECTRICO

21.12.98

Connettori originali
Original connector
Connecteurs d'origine
Conexiones originales

Iniettori Petrol injectors
Injecteurs Injectores

12V sotto chiave
12V accessories
12V apres contact
12V bajo llave

Bobina
Coil
Bobine d'allumage
Bobina

Fusibile max 5A
Fuse, 5A max
Fusible max 5A
Fusible max 5A

Non collegare
Do not connect
Ne pas connecter
No conectar

Timing RELAY
COD.370
G
A
S
3087A

Elettrovalvole gas
Gas solenoid valves
Electrovanne gaz
Electroválvulas gas

Blu Blue
Bleu Azul

Marrone Brown
Marron Marrón

Massa Ground
Masse
Masa

Nero Black
Noir Negro

Rosso Red
Rouge Rojo

Giallo Yellow
Jaune Amarillo

Regolazione n° giri soglia di commutazione
RPM changeover setting
Réglage régime moteur de commutation
Regulación de revolucione de la commutación

Bianco White
Blanc Blanco

Verde - Green wire
Fil vert - Cable verde

Massa Ground
Masse
Masa

Sensore metano o sensore GPL
To CNG or LPG sensor
Jauge méthane ou Jauge GPL
Al sensor para NGV o al sensor para GLP

INDEX
INDEX
SUMMARY
INDEX

Landi S.r.l., si riserva di modificare la presente scheda senza alcun preavviso, al fine di migliorare il funzionamento della vettura.	Landi S.r.l. reserves the right to modify this specification sheet without previous notice in order to improve the vehicle performances.	Landi S.r.l. se réserve le droit de modifier le présent schema, sans aunc préavis, afin d'améliorer le bon fonctionnement du véhicule.	Landi S.r.l. se reserva el derecho de modificar esta ficha técnica sin previo aviso al final de mejorar el funcionamiento del vehículo.
--	--	--	---